

# Erycina pusilla Genome Survey Report

## **Bioinformatics Center**

Version 3.0

Jan 16, 2012



## **CONTENTS**

1. CONVENTIONS	1
2. DESCRIPTION OF WORKFLOW	2
2.1 Pipeline of Experiment	2
2.2 Pipeline of Bioinformatics Analysis	3
3. BIOINFORMATICS RESULT	4
3.1 Background	4
3.2 Data statistics	4
3.3 17-mer analysis and genome size evaluation	4
3.4 Result of Assembly	6
3.5 GC-content and Sequencing depth analysis	7
3.6 Conclusions and recommendations.	8
4. DATA DOWNLOADING	9
5. CONTACT US	11



## 1. CONVENTIONS

Table 1.1 Notational conventions used in this document

Notation	Description		
Italic	A software or command of certain program. For example: "We		
	mainly use corrected reads to get a complete assembly of the		
	genome by SOAP de novo software".		
<b>Bold-normal</b>	Title. For example: "1 CONVENTIONS".		
Normal	Text. For example: "We extract sufficient DNA sample to		
	construct different insert-size libraries".		






#### 2. DESCRIPTION OF WORKFLOW

## 2.1 Pipeline of Experiment

The pipeline of the experiment is illustrated in Figure 2.1 as below:




**Figure 2.1** Pipeline of experiment. After the DNA sample(s) was(were) delivered, we did a sample quality test first. Then we used this(those) qualified DNA sample(s) to construct library, and we did a library quality test. At last, the qualified library would be used for sequencing.



## 2.2 Pipeline of Bioinformatics Analysis

The pipeline of the Bioinformatics Analysis is illustrated in Figure 2.2 as below:



**Figure 2.2** Pipeline of genome survey. When got the raw data, we filtered it first to get high quality reads. We used those clean data to do K-mer analysis and heterozygous simulation. Then we assembled them using *SOAPdenovo* software. We got the gc depth distribution by *SOAPaligner* result. After all, we knew the basic characteristics of the genome sequence and wrote the survey report.



#### 3. BIOINFORMATICS RESULT

### 3.1 Background

a. Species name: Erycina pusilla

b. Sample name & Number:

(1)8 (0111103635): used for 170bp library

(2)10 (0111103637): used for 500bp library

c. Evaluate Genome size: 1.5Gb

d. Designated reference sequences: No

#### 3.2 Data statistics

Table 3.1 Statistics of Clean Data

Lib ID	Insert	Read	Data(Mb)	Sequence
	Size(bp)	Length(bp)		Depth(X)
SZAXPI002377-12	170	100	39,431.64	26.29
SZAXPI002374-11	500	100	27,343.57	18.23
Total	-	-	66,775.20	44.52

This batch of sequencing produced 75.02Gb raw data. After low quality reads filtering, total 66.78Gb data was used for further analysis, if the genome size is estimated to be 1.5Gb in previous experiment, then the sequencing depth of filter data is expected to be 44.52X.

## 3.3 17-mer analysis and genome size evaluation

A K-mer refers to an artificial sequence division of K nucleotides. A raw sequencing read with L bp contains (L-K+1) K-mers if the length of each K-mer is K bp. The frequency of each K-mer can be calculated from the raw genome sequencing reads.



The K-mer frequencies along the sequencing depth gradient follow a Poisson distribution in a given data set. During deduction, the genome size  $G=K_num/Peak_depth$ , where the  $K_num$  is the total number of K-mer, and Peak depth is the expected value of K-mer depth. Typically, K=17.




Figure 3.1 17-mer depth distribution

**Table 3.2** 17-mer Data statistics

K	K-mer_num	Peak_depth	Genome Size(bp)	Used Bases(bp)	Used Reads	X
17	56,059,846,752	38	1,475,259,125	66,737,912,800	667,379,128	45.24
То	otal 66.74Gb d	lata was ret	ained for 17-mer	analysis. The	17-mer free	quency

distribution derived from the sequencing reads was plotted in Fig 3.1, the peak of the 17-mer distribution is about 38, and the total K-mer count is 56,059,846,752, then the genome size can be estimated (by formula: Genome Size=K-mer\_num/Peak\_depth) as 1.475Gb.

If the heterozygous rate is higher, then a small peak will be presented at 1/2 of Peak\_depth. So this K-mer analysis can be used to roughly determine the



heterozygous rate of a given genome.

Also, this distribution can be used to determine the repeat content of the genome. If this genome contains high proportion of repeat, the distribution will display a fat tail which indicates more than expect proportion of the genome have a high sequencing depth which may due to sequence similarly.

**Conclusion:** Genome size is 1.475Gb. The distribution display a small tail which indicates several repeat sequences in *Erycina pusilla*. In addition, there is no obvious peak at 1/2 of peak depth, but the percentage has a slightly higher value, which indicates the genome heterozygosity of *Erycina pusilla* is slightly high.

## 3.4 Result of Assembly


**Table 3.3** The result of assembly (using the data of 66.78Gb)

	Cont	Contig		ld	
	Size(bp)	Number	Size(bp)	Number	
N90	116	1,796,386	172	428,286	
N80	138	1,255,155	591	203,752	
N70	177	814,686	1,271	115,615	
N60	260	491,191	2,337	71,454	
N50	433	284,598	284,598 3,766		
Longest	22,540		62,894		
<b>Total Size</b>	681,771,944		756,111,956		
Total Number(	>=100bp)	2,431,836		1,047,905	
Total Number(	>=2kb)	38,521		80,990	

**Conclusion:** This is an initial version of assembly without gap filling. The slightly high heterozygous rate and repeat sequences might be the reason that the contig N50 is shorter than expected.



## 3.5 GC-content and Sequencing depth analysis



**Figure 3.2** Distribution of GC depth. The x-axis represents as GC content. The y-axis represents the average depth. We used 5 kb non-overlapping sliding windows to calculate the GC content and average depth among the windows.

The distribution of GC content versus sequencing depth will provide an eye about the sequencing bias or contamination. Usually, the genomic region with high or low GC content will possess a low sequencing depth compare to median GC content region. If the distribution of a given genome project is different from the expected pattern, it may indicate sequencing bias of contamination. If predicted to be contaminated, then we can eliminate the polluted reads by aligned the reads against bacteria, virus and fungous database.

Conclusion: According to the Distribution of GC depth, we align the sequences



with GC content higher than 56% and the lower depth (less than 24) sequences against NCBI nt database. The lower depth sequences matched with *Oncidium gower ramsey* and *Cymbidium sinense*, suggests that these sequences are likely heterozygosis of this genome. Result of the sequences with GC higher than 56% shows that the samples were contaminated by *Mycobacterium*.

#### 3.6 Conclusions and recommendations

- 1. The genome size of *Erycina pusilla* can be estimated as 1.475Gb.
- 2. Considering the distribution of 17-mer depth and the GC\_depth, we infer the *Erycina pusilla* contains slightly high heterozygous rate.
- According to the current data and assembly results, we think it might be a
  little risky to use the whole genome shotgun assembly strategy to complete
  the genome assembly.



#### 4. DATA DOWNLOADING

#### **Download**

Host: <a href="http://cdts.genomics.org.cn/">http://cdts.genomics.org.cn/</a>

ID: XXX

Password: XXX

#### Decompress the files

Some of the documents have been compressed under Linux environment as \*.gz, which can be decompressed by the following methods:

Unix/Linux user: gzip -d \*.gz

Windows user: winRAR

Mac user: Shell: gzip -d \*.gz

Some of the directories have been packed under Linux environment as \*.tar, which can be unpacked by the following methods:

Unix/Linux user: tar -xvf \*.tar

Windows user: winRAR

Mac user: Shell: tar -xvf \*.tar

#### FTP directory structure

l	l	Assemi	hl	w
		ASSCIII	נט	Lγ

| |-- README.txt

| |-- Raw Data

| | |-- lib\_id/\*\_1.fq.gz

| | |-- lib\_id/\*\_2.fq.gz

| | |-- InsertSize.txt

| |-- Clean Data

| |-- lib\_id/\*\_1.fq.gz.clean.dup.clean.gz

| |-- lib\_id/\*\_2.fq.gz.clean.dup.clean.gz

| |-- InsertSize.txt

-- Assembly Result

| |-- [Species name].scafSeq.gz



| |-- [Species name].scaftig.gz |-- Assembly Evaluation | |-- [Species name].GC\_content\_vs\_depth.png

Figure 4.1 FTP directory structure



## 5. CONTACT US

Service Hotline: 400-706-6615

Customer Service: customer@genomics.com.cn

Technical Support: tech@genomics.com.cn

Complaint Hotline: 010-80481175(Beijing) 0755-25273291(Shenzhen)